



# WEED BURNER AUSTRALIA

## Weed Burner Instructions

### Models WBK03 and WBK04 LP Gas.

### Component List



1 only Weed Burner with hose assembly with POL Gas cylinder fitting.

1 only Flint Lighter.

1 only Instructions.

### Assembly Instructions

Your Shields Weed Burner is fully assembled ready to use out of the box. Connect to your gas cylinder with the POL hand-tighten fitting and ensure it is done up tight. Check for leaks before lighting your weed burner.

#### **WARNING**

**Ensure all joints are correctly tightened and check with soapy lather solution, if bubbles appear at joints whilst under pressure follow assembly instructions again and recheck before operating.**

### Lighting Instructions

- Open the gas supply cylinder valve between half and one full turn. Open the small round knob valve on the weed burner handpiece anti clockwise just a little ( $\frac{1}{4}$  turn). At the same time light the burner using the flint lighter holding it approx 50 millimetres from the torch nozzle mouth.
- Use the round valve knob on the hand piece to adjust the flame this also allows you to set the pilot setting as required. Anti clockwise to open the valve and clockwise to close the valve. Pulling the lever opens the main gas flow and increases to full flow. Releasing the lever to reduces it back to the pilot flame.
- When finished turn off the cylinder valve first, allow the flame to burn out before closing valve on the hand piece ensuring that there is no gas in the hose when it is disconnected.

### Operating Instructions

- When lit, the burner should be held approximately 70 – 90 cm off the ground and gently pull the lever to increase the gas flame. Wave the burner across the weeds until the green weed leaves show signs of wilting, burn an area of about  $\frac{1}{2}$  a square metre at a time. Release the lever to conserve gas when changing areas. When moving onto the next area, always hold the flame away from the hose and cylinder. Then repeat the weeding process.

### Limited Warranty

- A twelve-month warranty exists from the date of purchase.
- Proof of purchase must be supplied when claiming replacement or repair.
- The warranty only extends to faulty manufacture of the above listed components.
- James Shields & Company reserves the right to replace or repair any of the components listed above.